

Step 3: Pull the sock over the decoy from behind. The heel goes on the belly of the decoy! Place the opening of the sock over the base of the beak, pull tight and stuff the overlap, using the blunt end of a pencil, into the 10mil hole that you have drilled (1)! You can stitch up the sock to make the hole tidier if you wish (2).

