

**Ah, so you do want more? Very good!**

Before putting on the sock, stick the plastic tube into the decoy until you reach the back inside the deke. Mark the depth, pull out the tube and cut it off! Make sure to have at least an inch still sticking out!

Wrap the outside bit in black insulation tape, maybe spraypaint it later or use green/brown tape...

