

VX800L/M FUEL COCK SET INSTALLATION PROCEDURE

FUEL COCK SET (P/NO. 44300-45810)

This fuel cock set contains following items.

- | | | |
|-------------------|-----------------------|-------|
| ① 44300-45C10 | Fuel cock | 1 pc |
| ② 09354-45853-300 | Hose | 1 pc |
| ③ 13685-45C00 | Union | 1 pc |
| ④ 09168-06026 | Gasket, fuel cock. . | 2 pcs |
| ⑤ 13523-46110 | Gasket, union | 1 pc |
| ⑥ 47913-45C10 | Label, fuel cock. . . | 1 pc |
| ⑦ 99501-38040-011 | Instruction | 1 pc |

INSTALLATION PROCEDURE

1. Remove the seat, the pillion rider grip, and the left and right frame covers together.
2. Turn the fuel cock to OFF position, disconnect fuel hose from fuel cock, and remove the fuel tank.
3. Remove the fuel cock lever from fuel cock, and remove the fuel cock from the fuel tank.
4. Install the new fuel cock ① to the fuel tank, and fuel cock lever to the fuel cock. Use the new gaskets ④.
5. Mount the fuel tank on the frame, and install the hose ② to the fuel cock vacuum pipe, and connect the fuel hose to the fuel cock. (Do not forget to install the clip and spring on the fuel hose.)
6. Remove the vacuum inspection screw from the rear carburetor body, and install the union ③ with new gasket ⑤.
7. Install the frame covers and the pillion rider grip.
8. Remove the fuel cock position sticker from the left frame cover, and attach the new label ⑥ to the proper position of the left frame cover.

