

Alphabetical & Numerical Index for DTC

ALPHABETICAL INDEX FOR DTC

NUMERICAL INDEX FOR DTC

X: Applicable —: Not applicable				X: Applicable —: Not applicable			
Items (CONSULT screen terms)	DTC	MIL Illumination	Reference page	DTC	MIL Illumination	Items (CONSULT screen terms)	Reference page
ACCEL POS SENSOR	43	X	EC-139	11	X	CAM POS SEN (PUMP)	EC-69
ACCEL POS SW (F/C)	23	X	EC-106	12	—	MAS AIR FLOW SEN	EC-74
ADJUST RESISTOR	17	—	EC-92	13	X	COOLANT TEMP SEN	EC-79
CAM POS SEN (PUMP)	11	X	EC-69	14	—	VEHICLE SPEED SEN	EC-83
CONT SLEEV POS SEN	15	X	EC-87	15	X	CONT SLEEV POS SEN	EC-87
COOLANT TEMP SEN	13	X	EC-79	17	—	ADJUST RESISTOR	EC-92
CRANK POS SEN (TDC)	47	X	EC-144	18	X	F/INJ F/B 2	EC-96
ECM 1	27	X	EC-111	21	—	F/INJ TIMG F/B	EC-101
ECM 2	31	X	EC-111	22	X	F/INJ F/B	EC-96
ELECTRIC GOV	25	X	EC-96	23	X	ACCEL POS SW (F/C)	EC-106
FCV SHORT	37	X	EC-130	25	X	ELECTRIC GOV	EC-96
FUEL CUT S/V 1	36	X	EC-130	27	X	ECM 1	EC-111
FUEL CUT S/V 2	38	X	EC-130	28	X	OVER HEAT	EC-113
FUEL TEMP SENSOR	42	—	EC-135	31	X	ECM 2	EC-111
F/INJ F/B	22	X	EC-96	33 *1	—	I/C INT/A TEMP SEN	EC-122
F/INJ F/B 2	18	X	EC-96	34	—	NEEDLE LIFT SEN	EC-126
F/INJ TIMG F/B	21	—	EC-101	36	X	FUEL CUT S/V 1	EC-130
GOV CUT CIRCUIT	48	X	EC-149	37	X	FCV SHORT	EC-130
I/C INT/A TEMP SEN	33 *1	—	EC-122	38	X	FUEL CUT S/V 2	EC-130
MAS AIR FLOW SEN	12	—	EC-74	42	—	FUEL TEMP SENSOR	EC-135
NATS MALFUNCTION	141 - 148	X	EL section*	43	X	ACCEL POS SENSOR	EC-139
NEEDLE LIFT SEN	34	—	EC-126	47	X	CRANK POS SEN (TDC)	EC-144
NO SELF DIAGNOSTIC FAILURE INDICATED	55	—	—	48	X	GOV CUT CIRCUIT	EC-149
OVER HEAT	28	X	EC-113	55	—	NO SELF DIAGNOSTIC FAILURE INDICATED	—
VEHICLE SPEED SEN	14	—	EC-83	141 - 148	X	NATS MALFUNCTION	EL section*2

*1: When nothing is displayed or the meaningless symbol is displayed in the "Self-diag result" mode with CONSULT, perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM. Refer to EC-32.

*2: Refer to "NATS (Nissan Anti-Theft System)" in EL section.