

ENDER "BASSMAN" SCHEMATIC MODEL 5F6-A

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMETER
VALUES SHOWN + OR - 20%

